

**MOPAR**

**INSTRUCTIONS FOR INSTALLING  
MOPAR GLOVE COMPARTMENT  
LIGHT PACKAGE  
PART NO. 2256 383**

**MOPAR**

**ON  
1962 VALIANT, LANCER, PLYMOUTH, DODGE, CHRYSLER NEWPORT AND "300"**

Plug into Female Terminal (Pink Wire)  
removed from Fuse Block Terminal  
marked "Door and Stop Lamp"

Plug into Male Terminal of  
Fuse Block marked  
"Door and Stop Lamp"

Bulb

Socket and Switch Assy.

VALIANT AND LANCER

1. Mount switch and socket in hole located in upper left corner of Glove Box. (Insulator in package should be assembled to male terminal after switch and socket assembly is installed in hole)
2. Route wire down the left side of Glove Box to Fuse Block.
3. Connect to Fuse Block.

PLYMOUTH AND DODGE

1. Locate 2 holes punched in upper right of Glove Box flange and mount bracket with screws furnished in package.
2. Mount switch and socket in bracket hole. (Insulator in package should be assembled to male terminal after switch and socket assembly is installed in hole)
3. Route wire through upper right of Glove Box. Install wiring clip in instrument panel flange about 6" above base of box. Route wire through this clip to Fuse Block.
4. Connect to Fuse Block.

**NOTE:** Some early production models have a hump on the inside top of the Glove Box that interferes with the operation of the Switch and prevents closing of the Door. Where this condition exists, neatly cut out a portion of the hump so that Switch Button contacts the inside metal edge of the Glove Box Door.

CHRYSLER

1. Mount switch and socket in hole located in upper right corner of Glove Box. (Insulator in package should be assembled to male terminal after switch and socket assembly is installed in hole)
2. Route wire through upper right of Glove Box. Install wiring clip on instrument panel flange about 6" above base of box. Route wire through this clip to Fuse Block.
3. Connect to Fuse Block.

**CHRYSLER MOTORS CORPORATION  
SERVICE PARTS AND ACCESSORIES DIVISION MOPAR  
P.O. BOX 1718 DETROIT 31, MICHIGAN**